



ENSURE LOCK IS REMOVED FROM MORTICE BEFORE DRILLING HOLES.  
TO PREVENT POSSIBLE DAMAGE TO DOOR FACE DO NOT DRILL RIGHT THROUGH DOOR.



NOTE: REBATE KITS SUIT 30 AND 38mm BACKSETS ONLY.

**HAND OF DOOR ACCORDING TO ENGLISH PRACTICE**



- Determine hand of lock required from chart above.
- Ensure only holes required by handing, function and furniture are cut into door.
- Disregard instructions referring to features not required.
- The lock is supplied in passage mode. The anti-lockout function is de-activated.
- The lock is always hold back capable, no setting is required. Hold back can be activated at any time - unless anti-lockout is selected.

**1 LOCK SETTING**

- Where cylinders or turn knobs are required, remove the cylinder plugs from the lock using a small screwdriver.
- Set the required lock function as per **SETTING AND OPERATING INSTRUCTIONS**.

**2A LOCKING ADAPTOR INSTALLATION**

- Rotate the locking adaptor so one leg is pointing towards the locking bar.
- With the locking bar in the unlocked (up) position; fit the locking adaptor into the lock. Ensure the cam is engaged within the locking bar.
- Secure by pressing in the cylinder retainer pin.

**2B LATCHING ADAPTOR INSTALLATION**

- Depress the latch bolt and fit the latching adaptor.
- Secure by pressing in the cylinder retainer pin.
- **Note: The face plate must be fitted to ensure correct function.**

**3 DOOR PREPARATION - LOCK SIDE**

**SPACER DIMENSIONS**

- 11
- 27
- 263

- Establish height that lock will be on the door.
- Use spacer as template to mark required cutout in the rebate.
- Cut recess allowing front of spacer to be flush with front of rebate.
- Cut mortice in door as per sizes shown on template.
- Determine what lever, cylinder or turn knob holes are required.
- Drill required furniture holes from both sides of door.

**DOOR PREPARATION - LOCK SIDE**

- Rotate latch bolt to correct handing and fit face plate using supplied 8mm long screws.

STRIKE SIDE | LOCK SIDE

Viewed from this direction

### 4 CYLINDER INSTALLATION

- Remove 8mm long mounting screws and face plate.
- Place lock into mortise.
- Place the cylinder into the lock.
- Secure by pressing in the cylinder retainer pin, ensuring the pin is flush with the lock case.
- For cylinder cam selection refer to **SETTING AND OPERATING INSTRUCTIONS**.
- Secure face plate using supplied 8mm long screws ensuring correct bolt handing.

### 5 LOCK INSTALLATION

- Drill 2.5mm pilot holes and secure the lock using the supplied 45mm long screws.

### 6 SPINDLE INSTALLATION

- Fit spring to spindle and then fit into lock hubs.
- Install furniture according to instructions.

### 7 DOOR PREPARATION - STRIKE SIDE

STRIKE DIMENSIONS

- Use strike as a template to mark required cutout onto the door.
- Mortise door frame to allow strike to sit flush with lower face.
- Mortise recess for latch bolt 15mm deep.
- For electric mortice lock magnets, drill  $\text{Ø}25 \times 2\text{mm}$  deep and  $\text{Ø}19 \times 20\text{mm}$  deep as shown.

Viewed from this direction

### 8 STRIKE INSTALLATION

- For electric mortice locks, insert magnet in hole.
- Drill 2.5mm pilot holes and secure the strike plate using the supplied 30mm long screws.

### STRIKE OPTIONS FOR REBATE KITS

<p><b>5782-RKCW</b> Clockwise rebate kit strike</p>	<p><b>5782-RKACW</b> Anti-clockwise rebate kit strike</p>
---	---

