


# 3540 SERIES MORTICE DEADLOCK

With FABRICATOR COVER PLATE for METAL DOORS


## 1 PREPARING DOOR

Cut opening in door to suit cover plate and drill holes to suit function required.


### CYLINDER




### TURN KNOB



### LEVER OR ESCAPE TURN KNOB




### LEVER FURNITURE




\* Standard Backset \*\* Extended Backset



## 2 FITTING ADAPTORS




### TURNKNOB ADAPTOR





With the bolt retracted, assemble adaptor through the internal cylinder hole.

Engage adaptor gear with actuating lever gear and secure adaptor with retainer pin.

Ensure retainer pin is fully inserted to firmly anchor adaptor.





### ANTI-LOCKOUT ADAPTOR



Assemble lever handle adaptors as shown. Thickness 2.0 to 2.7mm, use washer. Thickness 2.8 to 3.2mm, no washer required.

## 3 INSTALLING LOCK

With the bolt extended, insert the lock into the door cavity.




1. Secure with 2 M4 x 11mm C'sunk head screws provided.
2. Rotate Rear Support screw until it bears against the back inside wall of the door cavity as shown. This provides greater lock stability.

DO NOT USE IF GLASS IS VISIBLE IN SECTION


Rear Support Screw

CYLINDER




Assemble cylinder and secure with retainer pin . Ensure retainer pin is fully inserted to firmly anchor cylinder. Fit cylinder trim clip and cylinder trim.

ESCAPE TURN KNOB




Secure Escape Turn Knob assembly with 2 M5 X 15mm C'sunk head screws provided.

CYLINDER TURN




Assemble cylinder turn and secure with retainer pin. Ensure retainer pin is fully inserted to firmly anchor cylinder. Fit cylinder trim clip and cylinder trim.

TURN KNOB




Cut connecting bar to allow 10mm to protrude from door face. Secure Turn Knob assembly with 2 M5 X 15mm C'sunk head screws provided.

LEVER




Secure Lever Handle assembly with 2 M5 X 15mm C'sunk head screws provided.

LEVER FURNITURE



Assemble cylinder and secure with retainer pin. Ensure retainer pin is fully inserted to firmly anchor cylinder. Secure lever handle and opposing trim plate with 2 M5 X 15mm C'sunk head screws provided.


COVERPLATE



Secure Coverplate to lock with 3 M4 x 11mm C'sunk head screws provided.

Cutting of Bolt Hole 3540, 3542 Only


Cut hole in door jamb as shown.



Fitting of Sliding Door Strike - 3541 Only

Cut opening in door jamb to suit strike plate and drill holes as shown.

Drill 2 holes Ø4.0 & C'sunk Ø6.0 x 90°



- Assemble supplied T-Screws to back of strike body. (Refer to table below)
- Insert strike assembly into cavity.
- Tighten 2 T-Screws with Allen key supplied until T-screw fastens against back wall of section.
- Secure strike assembly into door jamb with 2 M3.5 X 10mm C'sunk head screws supplied and attach strike cover.

DO NOT USE T-SCREWS IF GLASS IS VISIBLE IN SECTION.

Depth of Section	Length of T-screw
Up to 38mm	15mm
38 to 48mm	25mm
48 to 58mm	35mm